



Place 120Ω terminating resistors on either end of the bus. The RA-400 has an internal resistor controlled by jumper J13; Short J13 to terminate bus at RA-400 (factory default).



				DYNAGEN TECHNOLOGIES INC.			
				RA-400 System Wiring Diagram			
SIZE	DATE	DWG NO.	REV				
	September 23, 2014	DWG1453	2.0				
SCALE:	NTS	DRAWN CC	APPROVED				